






TENT

3 Sectioned

Pole

- 1. SPREAD OUT TENT AND ROPES. DRIVE STAKES 4 FT. OUT FROM EDGE OF TENT. TWO AT EACH CORNER, ONE AT EACH SIDE POLE POSITION.
- 2. FASTEN ROPES TO STAKES LEAVING LOOPED END AND ABOUT 7 FT. OF SLACK.
- SET UP TWO PIECE SIDE POLES WITH TIPS THROUGH GROMMETS. ANGLE POLES AT ABOUT 45 DEGREES. (SEE 3A) NOTE: ALL GUY ROPES MUST BE OVER POLE TIPS.
- 4. SET UP CENTER POLES. BE CERTAIN SNAP BUTTONS ARE SECURED.
- 5. INSERT STAKES NEAR THE CENTER POLE.
- 6. PUSH SIDE POLES TO VERTICAL. ADJUST AND TIGHTEN GUY ROPES. (SEE 6A & 6B)
- 7. TIE CENTER TETHER ROPE TO POLE. (SEE 7)
- 8. SMALL DIAMETER CORD IS ATTACHED TO CENTER RINGS AND STAKED STRAIGHT DOWN. (SEE 8)
- 9. WHEN TAKING DOWN TENT, MAKE SURE ALL TAPE OR TAPE RESIDUE IS REMOVED BEFORE ROLLING UP.

PARTS LIST (20' X 20' CANOPY) • 9 SIDE/END POLES (19 SECTIONS) • 13 STAKES










6B







\$75.00 CLEANING FEE IF WET OR DIRTY!





