

40' OBSTACLE COURSE

L W H
40' x 13' x 13'



- 2 1.0 H.P. Blowers, drawing 10-15 amps each.



- 2 Sections



- 6 Stakes & Ropes (call "MISS DIG" 811 before pounding stakes)

- If on asphalt, 6 cement buckets/weights & tarp



- 2 - 12 gauge extension cords, \$75.00 fee each if not returned.

- \$75 cleaning fee IF returned Wet/Muddy

YOU PROVIDE:

- At least two adult operators.
- 2 -15 amp dedicated circuits (maximum distance: 50 feet)



Installation and Set-Up

Area must be dry and free of debris (ie: sticks, stones, broken glass, etc.)

Position on a flat area approximately 45L x 14W x 16H

The obstacle course will be rolled from the outer ends (entrance & exit) into the center.
(The center is Velcro ends that will be attached to make the 2 pieces a complete unit.)

1. Unroll the sections one section at a time.
Place both sections with flaps together and unroll outward. 1 section at a time.



2. Then match the Velcro where the units meet to join the two halves.



3. On each side of the unit there are also vents that will need to be Velcroed closed during inflation and while the unit is being operated.



4. Secure stakes 75% buried at each corner and each side of slide. Loosely attach tie-downs.

5. Insert blower in the tubes in each section and secure with strap & clip already affixed to unit.



6. Turn blowers on by using black switch on each blower unit.



7. The unit will take approximately 5 minutes to inflate fully.



8. Secure immediately to stakes to prevent the unit from shifting.



Proper Deflation and Return of Obstacle Course

1. Clear area
2. Turn off blower and remove from tubes



3. Open center vents at entrance and exit.
4. Open zippers on side vents



5. Take out stakes
6. Separate sections by taking apart Velcro.



7. Fold each section into thirds.
8. Roll from outer ends towards the center.



ENTER AT OWN RISK!

BUT ONLY IF AN ATTENDANT IS AT ENTRANCE!

HOW TO SUPERVISE THIS RIDE:

1. You must instruct participants before they enter:

REMOVE SHOES AND EYEGASSES

NO GUM OR ANY SHARP OBJECT

NO FLIPS DOWN THE SLIDE!

**STAY IN LINE AND WAIT FOR OPERATOR'S
SIGNAL TO START**

2. If the unit deflates tell kids not to panic and have them exit the ride IMMEDIATELY.

Check the electrical plugs and tubes for the cause of air loss.

Check blower to see if air intake has been obstructed.

**ANYONE NOT FOLLOWING THE RULES WILL BE
REMOVED FROM THIS RIDE!**

HAVE A  AND SAFE EVENT

PATRON RESPONSIBILITY

There are risks in the participation in or on any amusement ride, device or attraction.

Patrons of an amusement ride, device or attraction – by participation – accept the risks which are posted.

Patrons have a duty to exercise good judgment and act in a responsible manner while using the amusement attraction and to obey all oral or written warnings, prior to and during participation.

Patrons have a duty to not participate on any amusement device or attraction while under the influence of drugs or alcohol or due to health conditions.

Patrons have a duty to properly use all safety equipment provided.

DO NOT ENTER ANY INFLATABLE AMUSEMENT DEVICE IF OPERATOR IS NOT PRESENT, RAINING, WIND OVER 15-20 MPH, LESS THEN 40 ° OUT, AND AT LEAST 30 MINUTES AFTER ANY LIGHTNING OR THUNDER.
