Animal Kingdom

L		W		H
20’	x	18’	x	5’

- ☐ HP Blower

- ☐ (4) Stakes
  (call “MISS DIG” 811 before pounding stakes.)

- ☐ Stakes should be buried 75% deep and at no more than a 30 degree angle.

Installation and Set-Up

Area must be dry and free of debris (ie: sticks, stones, broken glass, etc.)

Position on a flat area approximately 22’ x 22’
Unroll - you will be unrolling from the back to the front.

Close vents on both sides of unit (zipper plus velcro!)

Insert blower in any tube, it doesn’t make any difference. Use the tube that is closer to the power source, maximum of 50 feet. Tie off the other tube securely.

Turn on blower and leave running for period of use.

Proper Deflation and Return of Unit

1. Clear area
2. Take out stakes
3. Turn off blower and remove from tube
4. Open other tube for DEFLATING only
5. Open zippers on side vents

Fold into Thirds

ROLL FROM FRONT TO BACK (helps air escape through tubes as you roll it up)

HAVE A FUN AND SAFE EVENT

PATRON RESPONSIBILITY

There are risks in the participation in or on any amusement ride, device or attraction.

Patrons of an amusement ride, device or attraction – by participation – accept the risks which are posted.

Patrons have a duty to exercise good judgement and act in a responsible manner while using the amusement attraction and to obey all oral or written warnings, prior to and during participation.

Patrons have a duty to not participate on any amusement device or attraction while under the influence of drugs or alcohol or due to health conditions.

Patrons have a duty to properly use all safety equipment provided.

DO NOT ENTER ANY AMUSEMENT DEVICE
IF OPERATOR IS NOT PRESENT.

Place this at the ticket table or close to the amusement device for patrons to read.